

WHY LONG SHOE HORN

5moonsun5

To make your selection process easier, here at 5moonsun5 we gathered everything you need to know about shoe horns.

WHAT IS A SHOE HORN?

A shoe horn is a tool used to help your foot glide easily into your shoe. Basically, the tool provides a smooth ramp that pulls back the heel of your shoe

WHY SHOULD YOU USE A SHOE HORN?

Shoe horns are not just useful at easing your foot into a shoe. While comfort is a notable feat in itself when it comes to tight shoes, these tools are also useful at preserving your shoes.

SHORT SHOE HORN

Sit down on a chair or stool. Position your shoe horn so the scoop is upwards and facing your heel. Slip your foot into the shoe. Remove the shoe horn when your foot is fully in the shoe.

LONG SHOE HORN

Remain standing. Position your shoe horn so the scoop is upwards and facing your heel. Hold onto the handle and slide your foot down the tool and into your shoe. Remove the shoe horn when your foot is fully in the shoe.

CHOOSING THE RIGHT TEXTURE

For those looking for quick results with ease, the smooth texture of metal is perfect at helping socks slide.

CHOOSING THE RIGHT LENGTH

If it is easiest to put your shoes on while standing, the better option is to go with a long shoe horn. On the other hand, if you sit on a chair when sliding on your shoes, it will be easier to do so with a shorter shoe horn.

MONEY

whether long shoehorn or short shoehorn price will be worth to their quality . 5moonsun5 will never compromise on quality