



## Mazdaspeed 3 & 6 HPFP COVER KIT (Fitment is for FMIC converted cars only)

### Required tools

- 8mm Socket, extension & ratchet for removing factory bolts.
- 5mm Allen Wrench for installing the new cover bolts.
- Tools to remove and install upper charge pipe if needed.

Thank you for purchasing our mazdaspeed 3 & 6 HPFP cover. This is a very simple installation and can be performed in a few minutes using only basic hand tools.

### Step #1

Unbox your kit and lay out your hardware carefully.

- 2 x M6 bolts
- 2 x M6 washers
- 2 x Tall aluminum spacers
- 2 x Short aluminum spacers
- 2 x Black rubber o-rings



### Step #2

Prepare the cover for installation

Insert the 2 M6 Bolts into the M6 Washers insert 1 bolt / washer into a mounting hole on the cover. Slip both a tall and short spacer over the bolt on the back side and then slide an o-ring over the bolt to hold the spacer in place.



Repeat for the other mounting hole



### Step #3

Prepare the vehicle for installation

Remove the two bolts that the red arrows are marking. (these bolts will not be reused)



Make sure the ground wire stays in place (red arrow) while bolting the cover onto the fuel pump housing.



Bolt the cover in place. Start by hand threading the screws in. The cover has a little bit of adjustment room so make sure it is sitting straight and finish by tightening with a 5mm allen wrench until snug.



Enjoy