


#### SINGLE DEPTH P2 HUMIDIFICATION PARTS LIST






## ATTACH AB7770 SPRAYERS TO MOTORS. NOTE SPRAYER TO MOTOR ORIENTATION FOR PROPER TUBE ROUTING




- 1. SCREW ON (4)P6269 APPROXIMATELY 5mm ON TO STUD
- 2. PLACE AB7770 ON TOP OF NUTS
- 3. WRENCH TIGHTEN (4)P6433 NUTS TO TOP OF STUDS
- 4. WRENCH TIGHTEN P6269 UP TO BOTTOM OF PLATE


#### **MOUNTING HOLES FOR AB7768**




### ATTACH AB7768 TO INSIDE OF ECU FRAME AS SHOWN



## TUBE ROUTING IN ECU FRAME (FAN ASS'Y REMOVED FOR CLARITY)




### TUBE ROUTING THROUGH FAN ASSY




#### MOUNT VALVE ASSEMBLIES IN CONSOLE

#### EXISTING MOUNTING HOLES IN CONSOLE PLATE



#### DRILL HOLES THROUGH CONSOLE BACK



# TUBE ROUTING THROUGH BACK OF CONSOLE (HEATING COILS AND SUPPORT LEG REMOVED FOR CLARITY)

