



SL-USA / Swing-arm Suspension Lock

Description	Quantity
Upper Rear Rack Bracket	1
Lower Hitch Bracket	1
3/8" x 2-1/4" Locking Pin	2
5/16" x 2-1/4" Locking Pin	1
5/8" x 4" Bent Hitch Pin	1
R-Pin	1
Instruction Manual	1

Suspension Lock Mounting& Assembly:

1. Attach the Upper Rear Rack Bracket to the Rear Rack of the ATV, using the (2) 3/8" Locking Pins. Note: Pins may not fit as shown! Depending on your OEM rack some modifications to the Upper Bracket may be needed to fit your ATV Rack.
2. Insert the Upper Rear Rack Bracket into the Lower Hitch Bracket (See photo on lower left).
3. Attach the Lower Hitch Bracket using the provided 5/8" Bent Hitch Pin to the DirtWorks 3-Point Hitch.
4. Either Extend or compress the ATV Suspension, to align the holes in each tube, and pin the two tubes together using the 5/16" Pin.

Suspension Lock Use:

- The SL-USA suspension lock is designed to allow you to quickly and easily Lock out the ATV's Suspension, allowing the DirtWorks 3-Point Hitch system to work to its' full potential. It will also provide additional support when using with DirtWorks on an Independent Suspension ATV.



Kolpin Outdoors, Inc.
 205 N. Depot Street, Fox Lake, WI 53933
 Phone #: (877) 9KOLPIN or (920) 928-3118
www.kolpin.com
customerservice@kolpin.com