



## KEY TO WIRING DIAGRAM - EXPLORER CAB MODELS

<i>No.</i>	<i>Description</i>	<i>No.</i>	<i>Description</i>																																							
1.	Starter motor	15.	Master / starter switch																																							
2.	Alternator	16.	Horn-push																																							
3.	Battery	17.	Wiper motor																																							
4.	Horn	18.	Wiper switch																																							
5.	Headlight	19.	Washer switch																																							
6.	Washer pump	20.	Heater switch																																							
7.	Side / flasher light combined - R.H.	21.	Plough light switch																																							
8.	Side / flasher light combined - L.H.	22.	Main beam / dip switch																																							
9.	Heater	23.	Side / head light switch																																							
10.	Stop light switch	24.	Interior light																																							
11.	Fuel tank unit	25.	Direction indicator (flasher) switch																																							
12.	Temperature transmitter	26.	Flasher unit																																							
13.	Safety start switch	27.	Trailer flasher warning light																																							
14.	Fuses	28.	Tail / flasher / stop light combined - R.H.																																							
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Fuse no.</th> <th style="text-align: center;">Amp</th> <th style="text-align: center;">Description</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">8</td> <td>L.H. Side &amp; tail lights</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">8</td> <td>R.H. Side &amp; tail lights</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">8</td> <td>Plough lights</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">10</td> <td>Headlight dip beam</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">10</td> <td>Headlight main beam</td> </tr> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;">8</td> <td>Wiper / washer</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">8</td> <td>Stop lights</td> </tr> <tr> <td style="text-align: center;">8</td> <td style="text-align: center;">8</td> <td>Flasher indicators</td> </tr> <tr> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> <td>Heater</td> </tr> <tr> <td style="text-align: center;">10</td> <td style="text-align: center;">10</td> <td>Horn</td> </tr> <tr> <td style="text-align: center;">11</td> <td style="text-align: center;">10</td> <td>Cigar lighter &amp; hazard</td> </tr> <tr> <td style="text-align: center;">12</td> <td style="text-align: center;">8</td> <td>Spare</td> </tr> </tbody> </table>	Fuse no.	Amp	Description	1	8	L.H. Side & tail lights	2	8	R.H. Side & tail lights	3	8	Plough lights	4	10	Headlight dip beam	5	10	Headlight main beam	6	8	Wiper / washer	7	8	Stop lights	8	8	Flasher indicators	9	8	Heater	10	10	Horn	11	10	Cigar lighter & hazard	12	8	Spare	29.	Tail / flasher / stop light combined - L.H.
Fuse no.	Amp	Description																																								
1	8	L.H. Side & tail lights																																								
2	8	R.H. Side & tail lights																																								
3	8	Plough lights																																								
4	10	Headlight dip beam																																								
5	10	Headlight main beam																																								
6	8	Wiper / washer																																								
7	8	Stop lights																																								
8	8	Flasher indicators																																								
9	8	Heater																																								
10	10	Horn																																								
11	10	Cigar lighter & hazard																																								
12	8	Spare																																								
		30.	Plough light																																							
		31.	Trailer socket																																							
		32.	Battery condition indicator																																							
		33.	Temperature gauge																																							
		34.	Fuel gauge																																							
		35.	No-charge warning light																																							
		36.	Flasher warning light																																							
		37.	Instrument panel lights																																							
		38.	Main beam warning light																																							
		39.	Voltage stabilizer																																							
		40.	Heater plug ('Thermostart') switch (if fitted)																																							
		41.	'Thermostart' (if fitted)																																							
		42.	Hazard switch																																							
		43.	Cigar lighter																																							

### CABLE COLOUR CODE

B.	Black	Y.	Yellow	LG.	Light green	O.	White
N.	Brown	U.	Blue	P.	Purple	S.	Slate
R.	Red	G.	Green	W.	White		

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour