


Jamesway Pilot



ÉWhen the Pilot Egg is oriented correctly in the flat, the cable will exit on the right side between two adjacent eggs before gently looping around to the front of the tray.