







TK15 Flashlight

Fenix TK15 features a powerful, tough, durable, and fully waterproof design intended for harsh outdoor conditions. Operating on two CR123A Lithium batteries or one 18650 Li-ion battery, the multi-level dimmer function makes a perfect combination of extreme brightness and ultra long runtime. The innovative side dimmer operation is very simple and rapid. Therefore TK15 will be the reliable partner when hunting, searching and rescuing, etc.

Technical Parameters

ANSI/FSC	Low	Mid	High	Turbo	Strobe
 OUTPUT	5 LUMENS	47 LUMENS	143 LUMENS	337 LUMENS	337 LUMENS
 RUNTIME	142h	23h	6h 25min	1h 50min	
 DISTANCE	215m				
 INTENSITY	11592cd				
 IMPACT RESISTANT	1.5m				
 WATERPROOF	IPX-8, underwater 2m				
ACCESSORIES	a holster, lanyard, a rubber switch boot and two spare o-rings				

- ◎ Cree XP-G LED (R5) with a lifespan of 50,000 hours
- ◎ Uses two 3V CR123A Lithium batteries or one 18650 Li-ion battery
- ◎ 135mm (Length) x 25.4mm (Diameter) x 34mm (Head)
- ◎ 152-gram weight (excluding batteries)
- ◎ Digitally regulated output - maintains constant brightness
- ◎ Reverse polarity protection, to protect from improper battery installation
- ◎ Tactical tail cap switch with momentary-on function
- ◎ Anti-roll, slip-resistant body design
- ◎ Made of durable aircraft-grade aluminum

- ◎ Premium Type III hard-anodized anti-abrasive finish
- ◎ Toughened ultra-clear glass lens with anti-reflective coating

Notice: The above-mentioned parameters (tested in lab by using quality CR123A primary Lithium batteries) are approximate and may vary between flashlights, batteries, and environments.

Operation Instruction

Flashlight turning on/off:

Depress the tail cap switch halfway to momentarily activate the light. Depress the tail cap switch completely to turn on the light and lock it. The light will stay on until the tail cap switch is depressed completely to turn off.

Mode selecting:

Depress the side dimmer button in the front part of the flashlight once can select the outputs in the general mode in the order of Low-Mid-High-Turbo. Depress the side dimmer button for a while (about one second) to enter into the strobe mode. Another such depress can return to the general mode.

The flashlight can automatically memorize the output when switch off. However it fails to memorize the strobe mode.

Battery Replacement

Unscrew the tail cap to insert the batteries with the anode side (+) toward the light head, screw the tail cap back on to test.

Usage and Maintenance

- 18650 Li-ion batteries are industrial batteries and not for domestic use. Using inferior batteries or misusing batteries (short circuit or high temperature, etc) may cause combustion and explosion which will damage people and their property. Therefore when using such batteries, users will agree to take the relevant responsibility voluntarily. Quality Li-ion batteries with protective circuit can lower the risks to some degree.
- Please don't disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.
- Please use batteries of high quality, if the flashlight is not to be used for an extended period, remove the batteries, or the flashlight can be damaged by electrolyte leakage or battery explosion.
- The o-ring may be worn out after using for a long time. If it happens, please replace the o-ring with a new one to keep the flashlight properly sealed against water.
- Please clean the contacts of your light from time to time, especially if the light flickers or doesn't light up. There may be several reasons for a flickering or not working light:

Reason A: The battery needs replacing.

Solution: Replace batteries (Please confirm the correct installation of anode and cathode).

Reason B: The threads, PCB board contact or other contacts are dirty.

Solution: Clean the contact points with an alcohol soaked cotton swab.

If the above methods don't work, please contact the distributors and refer to the warranty policy.

Notice: The routine cleaning video can be watched and downloaded through Fenix official website, please log onto the service channel->“maintenance for light”.

Product Warranty

We will replace products afflicted with manufacturing defects within 15 days of purchase and repair a light free of charge within 24 months of purchase if problems develop with normal use; if repair is required after 24 months from the date of purchase, we will charge for parts. The total repair fee is dictated by the cost of the replaced materials.

Warranty Card Registration

We kindly suggest that you register your guarantee card on the official website of Fenixlight Limited. You can get an extra six-month warranty period once you have successfully registered. What's more, you could take part in the lottery of questionnaire at the same time.

Warning

TK15 is a high intensity lighting device and capable of causing eye damage, avoid shining the light directly into the eyes.

FENIXLIGHT LIMITED

Tel: +86-755-29631163/83/93 Fax: +86-755-29631181

<http://www.fenixlight.com>

E-mail: info@fenixlight.com

Address: 8/F, 2nd Building, Dong Fang Ming

Industrial Center, 33rd District, Bao' an,

Shenzhen 518133, China