E35 Ultimate Edition

From 900 lumen burst mode to the energy-conserving low mode (10 lumens), the E35 outdoor flashlight gives you total control over output and runtime. When the rechargeable option for the 18650 battery is not available, this dual-fuel capable light also works with primary lithium battery (CR123A). When it comes to user-interface, the all-function side switch is all you need for ON/OFF, output selection and instant burst.

Technical Parameters

	Burst	High	Mid	Low			
31/5	900	360	120	10			
	lumens	lumens	lumens	lumens			
OUTPUT							
()		3h	11h	140h			
RUNTIME							
	156m						
DISTANCE							
	6100cd						
INTENSITY							
N ₂	1m						
IMPACT							
RESISTANT							
***	IPX-8□underwater 2m						
WATERPROOF							
ACCESSORIES	Lanyard, spare o-ring						

Notice: The above-mentioned parameters (lab tested by Fenix using an ARB-L2 Liion battery) are approximate and may vary between flashlights, batteries and environments.

- © Cree XM-L2 U2 LED with a lifespan of 50,000 hours
- ⊚ Uses one 18650 rechargeable Li-ion battery or two 3V CR123A Lithium batteries
- ⊚ 130mm (Length) x 24mm (Diameter)
- Digitally regulated output maintains constant brightness
- © Reverse polarity protection guards against improper battery installation
- ⊚ Side switch on the head for simple and convenient operation

- © Capable of standing up securely on a flat surface to serve as a candle
- ⊚ Premium Type III hard-anodized anti-abrasive finish
- ⊚ Toughened ultra-clear glass lens with anti-reflective coating

Operation Instruction

ON/OFF

Press and hold the switch for 0.5 second to turn the light on or off.

Output selection

With the light on, press the switch to select the brightness level in the order of $High \rightarrow Mid \rightarrow Low$.

Burst Mode

Press and hold the side switch for one second to activate the Burst mode even if the light is off. When the switch is released, the light will returns to the previous condition.

Intelligent Memory Circuit

The light remembers the last used brightness level when the light is turn off and then on again.

Battery Specifications

Type	Dimensions	Nomina	Usability	
		l voltage		
FENIX ARB-L2	18650	3.7V	Recommende	√
			d	
Non-rechargeable	CR123A	3V	Recommende	√
Battery			d	
(Lithium)				
Rechargeable Battery	16340	3.7V	Banned	×
(Li-ion)				
Rechargeable Battery	18650	3.7V	Cautious	
(Li-ion)				
3.2VBanned ×Recharge	16340	3.2V	Usable	\checkmark
able Lithium iron				
phosphate battery				
18650				
Rechargeable Lithium				
iron phosphate battery				

Warning: Please do not mix batteries of different brands, size, capacity or type. Doing so may cause damage to the flashlight or the batteries being used.

18650 Li-Ion batteries are powerful cells designed for commercial applications and must be treated with caution and handled with care. Quality batteries with circuit protection will reduce the potential for combustion or explosion but cell damage or short circuiting are potential risks the user assumes.

Battery Replacement

Unscrew the light head to put in the battery with the anode (+) toward the light head, and then screw the light head back on.

Usage and Maintenance

- ⊚Please don't disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.
- ©Please use batteries of high quality, and take out the battery if you do not use the light for a long time, or the light can be damaged by electrolyte leakage or battery explosion.
- ⊚Unscrew the tail cap one-half turn or take out the battery to prevent accidental activation during storage or transport.
- ⊚The o-ring may be worn out after Long-term use. If it happens, please replace the o-ring with a new one to keep the flashlight properly sealed against water.
- ⊚Please clean the contacts of your light from time to time, especially if the light flickers or doesn't light up. There are several reasons for a flickering or not working light:

Reason A: The batteries need replacing.

Solution: Replace the batteries (Please confirm the correct installation of anode and cathode).

Reason B: The threads, PCB board contact or other contacts are dirty.

Solution: Clean the contact points with an alcohol soaked cotton swab.

If the above methods don't work, please refer to the warranty policy before contacting your authorized distributor.

Product Warranty

We will replace products afflicted with manufacturing defects within 15 days of purchase and repair a light free of charge within 24 months of purchase if problems develop with normal use; if repair is required after 24 months from the date of purchase, we will charge for parts. The total repair fee is dictated by the cost of the replaced materials.

Product Registration

We kindly suggest that you register your product on the official website for Fenixlight Limited (www.fenixlight.com). You can get an extra six-month warranty period once you have successfully registered. By participating in an optional customer survey, you are entered in a drawing for free Fenix products.

Warning

E35 Ultimate Edition is a high-intensity lighting device capable of causing eye damage.

Avoid shining the light directly into anyone's eyes.

FENIXLIGHT LIMITED

Tel: +86-755-29631163/83/93 Fax: +86-755-29631181

http:www.fenixlight.com E-mail:info@fenixlight.com

Address: 8/F, 2nd Building, Dong Fang Ming

Industrial Center, 33rd District, Bao' an,

Shenzhen 518133, China